

H Shaped Water Wall

Parts List:

16x 100mm Screws

2x Wooden Spacers

1. Using a flat level surface, sit the centre panel on the 2 spacers.

2. Fix one of the end panels to the centre panel, using 8x 100mm screws and pre the drilled holes

3. Repeat previous step for opposite side.

4. Remove spacers

Required Tools

Drill or Screwdriver

2 Adults are needed to assemble this product

